

# POWER STEERING SYSTEM

4610

## ■ TABLE OF CONTENTS ■

<b>GENERAL INFORMATION .....</b>	<b>3</b>
1. Overview .....	3
2. System layout .....	4
3. Inspection and Service .....	8
4. Removal and Installation .....	12

---