

## 2. CIRCUIT DIAGRAM OF HORN

Location of horns: One at each side in engine compartment

Location of the theft deterrent horn: Under the battery tray in engine compartment

The theft deterrent horn is controlled by STICS in armed mode regardless of horn relay operation.

